

A Read this manual carefully before operating this vehicle.

OWNER'S MANUAL



LCP125/LCP125-I

BYB-FB199-E0



Introduction

FAU10114

Welcome to the Yamaha world of motorcycling!

As the owner of the LCP125/LCP125-I, you are benefiting from Yamaha's vast experience and newest technology regarding the design and manufacture of high-quality products, which have earned Yamaha a reputation for dependability.

Please take the time to read this manual thoroughly, so as to enjoy all advantages of your LCP125/LCP125-I. The Owner's Manual does not only instruct you in how to operate, inspect and maintain your scooter, but also in how to safeguard your-self and others from trouble and injury.

In addition, the many tips given in this manual will help keep your scooter in the best possible condition. If you have any further questions, do not hesitate to contact your Yamaha dealer.

The Yamaha team wishes you many safe and pleasant rides. So, remember to put safety first!

Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your scooter and this manual. If there is any question concerning this manual, please consult a Yamaha dealer.

EWA12412

WARNING

Please read this manual carefully and completely before operating this scooter.

Important manual information

EAU10134

Particularly important information is distinguished in this manual by the following notations:

\triangle	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.	
▲ WARNING	A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.	
NOTICE	A NOTICE indicates special precautions that must be taken to avoid damage to the vehicle or other property.	
TIP	A TIP provides key information to make procedures easier or clearer.	

^{*}Product and specifications are subject to change without notice.

Important manual information

EAUN0024

OWNER'S MANUAL
LCP125/LCP125-I
©2025 PT Yamaha Indonesia Motor
Manufacturing
1st edition, February 2025
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
PT Yamaha Indonesia Motor
Manufacturing
is expressly prohibited.
Printed in Indonesia.



- Hematlah pemakaian bahan bakar minyak, gunakan knalpot sesuai standar pabrik, dan lakukanlah perawatan berkala sepeda motor anda di Bengkel Resmi Yamaha.
- Milikilah SIM, gunakan helm ber-SNI dan taati rambu lalu lintas pada saat berkendara.

Table of contents

Location of important labels 1-1	Rear brake lever lock5-13	General maintenance and
	Fuel tank cap5-14	lubrication chart8-3
Safety information2-1	Fuel5-14	Removing and installing panels 8-8
Further safe-riding points 2-5	Catalytic converter5-15	Checking the spark plug8-10
Helmets 2-6	Seat5-16	Engine oil and oil strainer8-12
	Helmet holders5-16	Final transmission oil8-14
Description 3-1	Storage compartments5-17	Air filter and V-belt case air filter
Left view 3-1	Luggage hook5-18	elements8-15
Right view3-2	Power outlet5-18	Checking the throttle grip free
Controls and instruments 3-3	Sidestand5-19	play8-17
	Ignition circuit cut-off system5-20	Valve clearance8-18
Special features4-1		Tires 8-18
Stop and Start System	For your safety – pre-operation	Cast wheels8-20
(for equipped models)4-1	checks 6-1	Checking the front brake lever
Stop and Start System operation 4-1		free play8-20
CCU (Communication Control Unit)	Operation and important riding	Adjusting the rear brake lever
(for equipped models)4-4	points7-1	free play8-2 ⁻
	Engine break-in7-1	Checking the front brake pads
Instrument and control functions 5-1	Starting the engine7-2	and rear brake shoes8-2
Answer-back remote	Starting off7-3	Checking the brake fluid level 8-22
(for equipped models)5-1	Acceleration and deceleration7-3	Changing the brake fluid 8-23
Main switch/steering lock 5-3	Braking7-4	Checking the V-belt8-23
Keyhole shutter 5-4	Tips for reducing fuel	Checking and lubricating the
Indicator lights and warning	consumption7-4	cables8-24
lights 5-5	Parking7-4	Checking and lubricating the
Speedometer unit (for LCP125) 5-7		throttle grip and cable 8-24
Multi-function meter unit	Periodic maintenance and	Lubricating the front and rear
(for LCP125-I)5-7	adjustment8-1	brake levers8-24
Handlebar switches5-11	Tool kit8-1	Checking and lubricating the
Front brake lever 5-12	Periodic maintenance chart for	centerstand and sidestand 8-25
Rear brake lever 5-13	the emission control system8-2	Checking the front fork8-26

Table of contents

Checking the steering	8-26
Checking the wheel bearings	
Battery	
Replacing the fuses	
Vehicle lights	
Replacing a front turn signal	
light bulb	8-30
Replacing a tail/brake light bulb	
or a rear turn signal light bulb	8-31
Troubleshooting	
Troubleshooting chart	8-34
Scooter care and storage	
Matte color caution	
Care	
Storage	9-3
Otorago	
•	
Specifications	
Specifications	10-1
Specifications Consumer information	10-1 11-1
Specifications Consumer information Identification numbers	10-1 11-1 11-1
Specifications Consumer information	10-1 11-1 11-1
Specifications Consumer information Identification numbers	10-1 11-1 11-1 11-2

Location of important labels

EAUN2190

Read and understand all of the labels on your vehicle. They contain important information for safe and proper operation of your vehicle. Never remove any labels from your vehicle.



1



2

	र्वच्	
100kPa=1bar	kPa, psi	kPa, psi
İ	225, 33	250, 36
İ	225, 33	250, 36
		B92-F1668-00

FAU1026B

Be a Responsible Owner

As the vehicle's owner, you are responsible for the safe and proper operation of your scooter.

Scooters are single-track vehicles.

Their safe use and operation are dependent upon the use of proper riding techniques as well as the expertise of the operator. Every operator should know the following requirements before riding this scooter.

He or she should:

- Obtain thorough instructions from a competent source on all aspects of scooter operation.
- Observe the warnings and maintenance requirements in this Owner's Manual.
- Obtain qualified training in safe and proper riding techniques.
- Obtain professional technical service as indicated in this Owner's Manual and/or when made necessary by mechanical conditions.

 Never operate a scooter without proper training or instruction. Take a training course. Beginners should receive training from a certified instructor. Contact an authorized scooter dealer to find out about the training courses nearest you.

Safe Riding

Perform the pre-operation checks each time you use the vehicle to make sure it is in safe operating condition. Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. See page 6-1 for a list of pre-operation checks.

- This scooter is designed to carry the operator and a passenger.
- The failure of motorists to detect and recognize scooters in traffic is the predominating cause of automobile/scooter accidents. Many accidents have been caused by an automobile driver who did not see the scooter. Making yourself

conspicuous appears to be very effective in reducing the chance of this type of accident.

Therefore:

- Wear a brightly colored jacket.
- Use extra caution when you are approaching and passing through intersections, since intersections are the most likely places for scooter accidents to occur.
- Ride where other motorists can see you. Avoid riding in another motorist's blind spot.
- Never maintain a scooter without proper knowledge. Contact an authorized scooter dealer to inform you on basic scooter maintenance. Certain maintenance can only be carried out by certified staff.

A Safety information

- Many accidents involve inexperienced operators. In fact, many operators who have been involved in accidents do not even have a current driver's license.
 - Make sure that you are qualified and that you only lend your scooter to other qualified operators.
 - Know your skills and limits.
 Staying within your limits may help you to avoid an accident.
 - We recommend that you practice riding your scooter where there is no traffic until you have become thoroughly familiar with the scooter and all of its controls.
- Many accidents have been caused by error of the scooter operator. A typical error made by the operator is veering wide on a turn due to excessive speed or undercornering (insufficient lean angle for the speed).
 - Always obey the speed limit and never travel faster than warranted by road and traffic conditions.

- Always signal before turning or changing lanes. Make sure that other motorists can see you.
- The posture of the operator and passenger is important for proper control.
 - The operator should keep both hands on the handlebar and both feet on the operator footrests during operation to maintain control of the scooter.
 - The passenger should always hold onto the operator, the seat strap or grab bar, if equipped, with both hands and keep both feet on the passenger footrests. Never carry a passenger unless he or she can firmly place both feet on the passenger footrests.
- Never ride under the influence of alcohol or other drugs.
- This scooter is designed for onroad use only. It is not suitable for off-road use.

Protective Apparel

The majority of fatalities from scooter accidents are the result of head injuries. The use of a safety helmet is the single most critical factor in the prevention or reduction of head injuries.

- Always wear an approved helmet.
- Wear a face shield or goggles.
 Wind in your unprotected eyes could contribute to an impairment of vision that could delay seeing a hazard.
- The use of a jacket, substantial shoes, trousers, gloves, etc., is effective in preventing or reducing abrasions or lacerations.
- Never wear loose-fitting clothes, otherwise they could catch on the control levers or wheels and cause injury or an accident.
- Always wear protective clothing that covers your legs, ankles, and feet. The engine or exhaust system become very hot during or after operation and can cause burns.
- A passenger should also observe the above precautions.

Avoid Carbon Monoxide Poisoning

All engine exhaust contains carbon monoxide, a deadly gas. Breathing carbon monoxide can cause headaches, dizziness, drowsiness, nausea, confusion, and eventually death.

Carbon Monoxide is a colorless, odorless, tasteless gas which may be present even if you do not see or smell any engine exhaust. Deadly levels of carbon monoxide can collect rapidly and you can quickly be overcome and unable to save yourself. Also, deadly levels of carbon monoxide can linger for hours or days in enclosed or poorly ventilated areas. If you experience any symptoms of carbon monoxide poisoning, leave the area immediately, get fresh air, and SEEK MEDICAL TREAT-MENT.

- Do not run engine indoors. Even if vou try to ventilate engine exhaust with fans or open windows and doors, carbon monoxide can rapidly reach dangerous levels.
- Do not run engine in poorly ventilated or partially enclosed areas such as barns, garages, or carports.

 Do not run engine outdoors where engine exhaust can be drawn into a building through openings such as windows and doors.

Loading

Adding accessories or cargo to your scooter can adversely affect stability and handling if the weight distribution of the scooter is changed. To avoid the possibility of an accident, use extreme caution when adding cargo or accessories to your scooter. Use extra care when riding a scooter that has added cargo or accessories. Here, along with the information about accessories below, are some general guidelines to follow if loading cargo to your scooter: The total weight of the operator, passenger, accessories and cargo must not exceed the maximum load limit.

Maximum load:

158 kg (348 lb)

could cause an accident.

When loading within this weight limit, keep the following in mind:

Operation of an overloaded vehicle

- Cargo and accessory weight should be kept as low and close to the scooter as possible. Securely pack your heaviest items as close to the center of the vehicle as possible and make sure to distribute the weight as evenly as possible on both sides of the scooter to minimize imbalance or instability.
- Shifting weights can create a sudden imbalance. Make sure that accessories and cargo are securely attached to the scooter before riding. Check accessory mounts and cargo restraints frequently.
 - Properly adjust the suspension for your load (suspension-adjustable models only), and check the condition and pressure of your tires.
 - Never attach any large or heavy items to the handlebar, front fork, or front fender. Such items can create unstable handling or a slow steering response.
- This vehicle is not designed to pull a trailer or to be attached to a sidecar.

Safety information

Genuine Yamaha Accessories

Choosing accessories for your vehicle is an important decision. Genuine Yamaha accessories, which are available only from a Yamaha dealer, have been designed, tested, and approved by Yamaha for use on your vehicle. Many companies with no connection to Yamaha manufacture parts and accessories or offer other modifications for Yamaha vehicles. Yamaha is not in a position to test the products that these aftermarket companies produce. Therefore, Yamaha can neither endorse nor recommend the use of accessories not sold by Yamaha or modifications not specifically recommended by Yamaha, even if sold and installed by a Yamaha dealer.

Aftermarket Parts, Accessories, and Modifications

While you may find aftermarket products similar in design and quality to genuine Yamaha accessories, recognize that some aftermarket accessories or modifications are not suitable because of potential safety hazards to you or others. Installing aftermarket products or having other modifications performed to your vehicle that change any of the vehicle's design or operation characteristics can put you and others at greater risk of serious injury or death. You are responsible for injuries related to changes in the vehicle.

Keep the following guidelines in mind, as well as those provided under "Loading" when mounting accessories.

- Never install accessories or carry cargo that would impair the performance of your scooter. Carefully inspect the accessory before using it to make sure that it does not in any way reduce ground clearance or cornering clearance, limit suspension travel, steering travel or control operation, or obscure lights or reflectors.
 - Accessories fitted to the handlebar or the front fork area can create instability due to improper weight distribution or aerodynamic changes. If accessories are added to the handlebar or front fork area, they must be as lightweight as possible and should be kept to a minimum.

- Bulky or large accessories may seriously affect the stability of the scooter due to aerodynamic effects. Wind may attempt to lift the scooter, or the scooter may become unstable in cross winds. These accessories may also cause instability when passing or being passed by large vehicles.
- Certain accessories can displace the operator from his or her normal riding position. This improper position limits the freedom of movement of the operator and may limit control ability, therefore, such accessories are not recommended.
- Use caution when adding electrical accessories. If electrical accessories exceed the capacity of the scooter's electrical system, an electric failure could result, which could cause a dangerous loss of lights or engine power.

A Safety information

Aftermarket Tires and Rims

The tires and rims that came with your scooter were designed to match the performance capabilities and to provide the best combination of handling, braking, and comfort. Other tires, rims, sizes, and combinations may not be appropriate. Refer to page 8-18 for tire specifications and more information on replacing your tires.

Transporting the Scooter

Be sure to observe following instructions before transporting the scooter in another vehicle.

- Remove all loose items from the scooter.
- Point the front wheel straight ahead on the trailer or in the truck bed, and choke it in a rail to prevent movement.
- Secure the scooter with tie-downs or suitable straps that are attached to solid parts of the scooter, such as the frame or upper front fork triple clamp (and not, for example, to rubber-mounted handlebars or turn signals, or parts that could break). Choose the lo-

- cation for the straps carefully so the straps will not rub against painted surfaces during transport.
- The suspension should be compressed somewhat by the tiedowns, if possible, so that the scooter will not bounce excessively during transport.

EAU57600

Further safe-riding points

- Be sure to signal clearly when making turns.
- Braking can be extremely difficult on a wet road. Avoid hard braking, because the scooter could slide. Apply the brakes slowly when stopping on a wet surface.
- Slow down as you approach a corner or turn. Once you have completed a turn, accelerate slowly.
- Be careful when passing parked cars. A driver might not see you and open a door in your path.
- Railroad crossings, streetcar rails, iron plates on road construction sites, and manhole covers become extremely slippery when wet. Slow down and cross them with caution. Keep the scooter upright, otherwise it could slide out from under you.
- The brake pads or linings could get wet when you wash the scooter. After washing the scooter, check the brakes before riding.

Safety information

- Always wear a helmet, gloves, trousers (tapered around the cuff and ankle so they do not flap), and a brightly colored jacket.
- Do not carry too much luggage on the scooter. An overloaded scooter is unstable. Use a strong cord to secure any luggage to the carrier (if equipped). A loose load will affect the stability of the scooter and could divert your attention from the road. (See page 2-3.)

Helmets

Operating this vehicle without an approved motorcycle helmet increases your chances of a severe head injury or death in the event of an accident. The majority of fatalities from motorcycle or scooter accidents are the result of head injuries. The use of a safety helmet is the single most critical factor in the prevention or reduction of head injuries.

Always select an approved motorcycle helmet

Pay attention to the following when choosing a motorcycle helmet.

- The helmet must meet the safety standard "SNI".
- The helmet size must match the size of the rider's head.
- Never subject a helmet to heavy shocks.

Wearing the helmet correctly

Always connect the chin strap. In the case of an accident, the helmet has a much less chance of coming off if the chin strap is connected.

Correct usage

EAUN0213



Wrong usage



ZAUU0007

Types of helmets and their usage

 Full-type: use only for riding at low to mid-range speeds

Safety information



ZAUU0005

• Full-face-type: use for riding at mid-range to high speeds



ZAUU0006

EAU10411


Left view



- 1. Front turn signal light (page 8-30/8-31)
- 2. Auxiliary light (page 8-30)
- 3. Headlight (page 8-30)
- 4. Luggage hook (page 5-18)
- 5. Tool kit (page 8-1)
- 6. Rear storage compartment (page 5-17)
- 7. Air filter element (page 8-15)
- 8. Final transmission oil filler cap (page 8-14)


- 9. Final transmission oil drain bolt (page 8-14)
- 10.V-belt case air filter element (page 8-15)
- 11. Engine oil drain bolt A (page 8-12)
- 12. Engine oil drain bolt B (page 8-12)

Right view



- 1. Brake/tail light (page 8-31)
- 2. Rear turn signal light (page 8-31)
- 3. Fuse (page 8-29)
- 4. Front brake fluid reservoir (page 8-22)
- 5. Front storage compartment (page 5-17)
- 6. Luggage hook (page 5-18)
- 7. Battery (page 8-27)
- 8. Spark plug (page 8-10)

Controls and instruments



- 1. Rear brake lever (page 5-13)
- 2. Left handlebar switches (page 5-11)
- 3. Speedometer unit/Multi-function meter unit (page 5-7/5-7)
- 4. Right handlebar switches (page 5-11)
- 5. Front brake lever (page 5-12)
- 6. Throttle grip (page 8-17)
- 7. Main switch (page 5-3)
- 8. Power outlet (page 5-18)

Special features

EAUA2241

Stop and Start System (for equipped models)



1. Stop and Start System indicator light "A"

The Stop and Start System stops the engine automatically when the vehicle is stopped in order to prevent noise, control exhaust emissions, and reduce fuel consumption.

When the rider turns the throttle grip slightly, the engine restarts automatically and the vehicle starts off.

ECA23961

NOTICE

When parking the vehicle or leaving the vehicle unattended, be sure to turn the main switch off. If the Stop and Start System is left turned on, the battery could become discharged and it may not be possible to restart the engine due to insufficient battery voltage.

TIP

- Although the engine normally stops at the same time as the vehicle, there may be a delay when operating the vehicle under 10 km/h, such as in heavy traffic.
- If you think the battery voltage is low because the engine cannot be started using the starter switch or for some other reason, do not turn on the Stop and Start System.
- Have a Yamaha dealer check the battery at the intervals specified in the periodic maintenance chart.


EAUA2190

Stop and Start System operation


FALIA2210

Activating the Stop and Start System

1. Turn the main switch on.



2. Set the Stop and Start System switch to "A".




Special features

- 3. The Stop and Start System activates and the indicator light comes on when the following conditions are met:
 - The Stop and Start System switch is set to "A".
 - After the engine was warmed up, the engine was left idling for a certain period.
 - The vehicle has traveled at a speed of 10 km/h or higher.



- 1. Stop and Start System indicator light "A"
 - 4. To turn off the Stop and Start System, set the Stop and Start System switch to "A".



TIP

- To preserve battery power, the Stop and Start System may not activate.
- If the Stop and Start System does not activate, have a Yamaha dealer check the battery.


EAUA2250

Stop the engine

The engine will stop automatically when the following conditions are met:

- The Stop and Start System switch is set to "A".
- The "A" indicator light on the multi-function meter is on.
- The vehicle is stopped with the throttle grip fully returned.

At this time, the "A" indicator light starts flashing to indicate that the engine is currently stopped by the Stop and Start System.




- 1. On
- 2. Flashing

EAUA2222

Restart the engine

If the throttle grip is turned while the Stop and Start System indicator light is flashing, the engine will automatically restart and the "A" indicator light will go off.




- 1. Flashing
- 2. On

WARNING

EWA18731

Do not turn the throttle grip too much or too quickly when the Stop and Start System is activated and the engine is stopped. Otherwise, the vehicle could start moving unexpectedly after the engine restarts.



TIP

- When the sidestand is lowered, the Stop and Start System is deactivated.
- If the Stop and Start System does not operate correctly, have a Yamaha dealer check the vehicle.

EAUA2230

Precautions when using the Stop and Start System


In order to prevent accidents due to improper operation, carefully read and observe the following precautions.

EWA18741

WARNING

When walking while pushing the vehicle, be sure to turn the main switch off. If the vehicle is pushed while the


Stop and Start System is left turned on, the engine could start and the vehicle could start moving if the throttle grip is turned accidentally.



EWA18751

WARNING

When placing the vehicle on the centerstand, be sure to turn the main switch off. If the vehicle is placed on the centerstand while the Stop and Start System is left turned on, the engine could start and the vehicle could start moving if the throttle grip is turned accidentally.



EWA18771

WARNING


- When leaving the vehicle unattended, be sure to turn the main switch off.
- Do not leave the Stop and Start System turned on when parking the vehicle. Otherwise, the engine could start and the vehicle could start moving if the throttle grip is turned accidentally.



EWA18781

WARNING

Before performing maintenance, be sure to turn the main switch off. If maintenance is performed while the Stop and Start System is turned on, the engine could start and the vehicle could start moving if the throttle grip is turned.



CCU (Communication Control Unit) (for equipped models)

This model is equipped with a CCU that allows your vehicle and smartphone to connect using Bluetooth wireless technology and the Yamaha Motorcycle Connect smartphone app. With this connection, notifications from SNS (social network service) apps, incoming phone calls and missed calls are signaled to you, and the battery level of your smartphone is displayed. The Yamaha Motorcycle Connect app also provides other information such as your last parking location, etc.

EWAN0070

WARNING

- Always stop the vehicle before operating your smartphone.
- Never take your hands off the handlebars while riding.
- Always concentrate on riding by keeping your eyes and mind on the road.

Special features

FCAN0150

NOTICE

The Bluetooth connection may not work in the following situations.

- In a location exposed to strong radio waves or other electromagnetic noise.
- At facilities nearby that are emitting strong radio waves (TV or radio towers, power plants, broadcasting stations, airports, etc.).

Pairing the CCU and your smartphone

1. Scan the QR code below and download the Yamaha Motorcycle Connect app.




TIP

Yamaha Motorcycle Connect may not work on all smartphone models and OS (operating system) versions.

- 2. Open the seat. (See page 5-16.)
- 3. Remove the CCU cover.



- 1. CCU cover
 - 4. Pull out the CCU and scan its QR code with your smartphone.



- 1. CCU (Communication Control Unit)
- 2. CCU QR Code
- 5. When pairing is complete, the Yamaha Motorcycle Connect icon and smartphone battery level meter will come on.



- 1. Yamaha Motorcycle Connect icon
- 2. Smartphone battery level meter

TIP


- Once paired, the smartphone is registered in the CCU. The next time the vehicle is turned on and the Yamaha Motorcycle Connect app is active, the connection will be automatically executed.
- Only one smartphone can be connected to the CCU at one time.

Scan the QR code below to see the certification number.



FAUN4940

Answer-back remote (for equipped models)



- 1. Answer-back remote
- 2. Answer-back remote button

The vehicle is equipped with a answerback remote. The answer-back remote can help you find the location of your parked vehicle. The answer-back remote operations are described below.

To find the location of your parked vehicle

Press the remote button to flash the turn signal lights twice and sound the electronic alert twice.

TIP

- If the answer-back remote is not used in nine days, the remote operation functions are automatically canceled to reduce load on the battery. When the main switch is turned to "ON" again, function is restored.
- Holding the answer-back remote improperly or other obstructions can reduce the effective range.

ECAN0110

NOTICE

The answer-back remote contains a battery and electronic circuits. Handle it carefully. Therefore:

- Do not place or store the answer-back remote in a storage compartment. The answer-back remote may be damaged from road vibrations or excessive heat.
- Do not drop the answer-back remote or subject it to strong impacts.
- Do not submerge it in water or other liquids.

- Do not place heavy items or excessive stress on the answerback remote.
- Do not expose it to excessively high temperature.
- Do not grind any remote or alter its shape.

Replacing the remote battery

Replace the battery if the answer-back function does not operate when the answer-back remote button is pushed.

FWA14724

MARNING


- The battery and other removable parts may cause injury if swallowed. Keep the battery and other removable parts away from children.
- Do not expose the battery to direct sunlight or other heat sources.

ECAN0240


NOTICE

 Take precautions to prevent the waterproof seal from being damaged or contaminated by dirt.


- Do not touch the internal circuits and terminals. This may cause malfunctions.
- Do not apply excessive force to the remote when replacing the battery.
- Make sure the battery is installed correctly. Confirm the direction of the positive/"+" side of the battery.



 Gently pry open the remote case as shown. Otherwise, have a Yamaha dealer replace the battery.



2. Remove the battery.




1. Battery

TIP

Dispose of the removed battery in accordance with local regulations.

3. Note the polarity of the battery and install it with the positive "+" side facing downwards as shown.

Specified battery: CR2032



- Battery
- 4. Gently snap the remote case closed.

Scan the QR code below to see the certification number.


85648/SDPPI/2022 13214





Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Main switch/steering lock



The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various main switch positions are described below.

TIP

The main switch/steering lock is equipped with a keyhole shutter. (See page 5-4 for keyhole shutter opening and closing procedures.)

EAU85043

ON

All electrical circuits are supplied with power and the vehicle lights are turned on. The engine can be started. The key cannot be removed.

EAUN0264

- To prevent battery discharge, do not leave the key in the "ON" position without the engine running.
- The headlight comes on automatically when the engine is started.

EAU10664

OFF

All electrical systems are off. The key can be removed.

EWA10062

WARNING

Never turn the key to "OFF" or "LOCK" while the vehicle is moving. Otherwise the electrical systems will be switched off, which may result in loss of control or an accident.

FAU10696

LOCK

The steering is locked and all electrical systems are off. The key can be removed.

To lock the steering


2

- 1. Push.
- 2. Turn.
 - 1. Turn the handlebars all the way to the left or right.
- 2. With the key in the "OFF" position, push the key in and turn it to "LOCK".
- 3. Remove the key.

TIP_____

If the steering will not lock, try turning the handlebars back to the right or left slightly.

To unlock the steering




- 1. Push.
- 2. Turn.

From the "LOCK" position, push the key and turn it to "OFF".

Keyhole shutter


EAU61101

To open the keyhole shutter



Insert the keyhole shutter key into the keyhole shutter receptacle as shown, and then turn the key to the right to open the keyhole shutter.

To close the keyhole shutter



Insert the keyhole shutter key into the keyhole shutter receptacle as shown, and then turn the key to the left to close the keyhole shutter.

Indicator lights and warning lights

LCP125-I



- 1. Stop and Start System indicator light "A"
- 2. Turn signal indicator light "◆ → "
- 3. Engine trouble warning light " ""
- 4. High beam indicator light "

 "

LCP125



- 1. Acceleration assist indicator light "ASST"
- 2. Engine trouble warning light " ""
- 3. Left turn signal indicator light "<a>"
- 4. Right turn signal indicator light ">"
- 5. High beam indicator light "

 "
- 6. Eco indicator light " ECO"

Turn signal indicator lights "←" and "→"

Each indicator light will flash when its corresponding turn signal lights are flashing.

High beam indicator light "≣■"

This indicator light comes on when the high beam of the headlight is switched on.

EAUN5060

EAU89430

Eco indicator light "

This indicator light comes on when the vehicle is being operated in an environmentally friendly, fuel-efficient manner. The indicator light goes off when the vehicle is stopped.

TIP _____

Consider the following tips to reduce fuel consumption:

- Avoid high engine speeds during acceleration.
- Travel at a constant speed.

Engine trouble warning light " "

This warning light comes on if a problem is detected in the engine or other vehicle control system. If this occurs, have a Yamaha dealer check the onboard diagnostic system.

TIP

When the vehicle is turned on, this light should come on for a few seconds and then go off. Otherwise, have a Yamaha dealer check vehicle. Stop and Start System indicator light "A" (for equipped models)

This indicator light comes on when the Stop and Start System activates. The indicator light will flash when the engine is automatically stopped by the Stop and Start System.

TIP _____

Even if the Stop and Start Switch is set to "A", this indicator light may not come on. (See page 4-1.)

EAUN5070

FAUN2831

Acceleration assist indicator light

" ASST "

This vehicle is equipped with a Smart Motor Generator (SMG) that not only starts the engine, but also works in hybrid function to assist with initial acceleration.

This indicator light comes on when the smart motor generator is assisting with acceleration. The indicator light goes off when the vehicle is stopped.

TIP

When battery voltage is low, the smart motor generator may not assist with acceleration.

FAUU0082

Speedometer unit (for LCP125)



- 1. Speedometer
- 2. Odometer
- 3. Fuel meter

The speedometer unit is equipped with a speedometer, an odometer and a fuel meter. The speedometer shows riding speed. The odometer shows the total distance traveled. The fuel meter indicates the amount of fuel in the fuel tank.

Multi-function meter unit (for LCP125-I)



- 1. Fuel meter
- 2. Incoming call icon "&"
- 3. SMG "ASSIST" icon
- 4. Speedometer
- 5. Multi-function display
- 6. Eco indicator "ECD"
- 7. Smartphone battery level meter
- 8. Yamaha Motorcycle Connect icon
- 9. Incoming notification icon "..."
- 10."RES/SEL" button

MARNING

Be sure to stop the vehicle before making any setting changes to the multi-function meter unit. Changing settings while riding can distract the operator and increase the risk of an accident.

TIP

Be sure to turn the main switch on before using the "RES/SEL" button.

FAUV0992

Incoming call icon "&"

This icon flashes when there is an incoming call to the connected smart-phone. If you do not answer the call, the icon stays on until you turn the vehicle off.

TIP

EWA12423

This function works only when the smartphone is connected to the vehicle.

EAUV1002

Incoming notification icon "."

This icon flashes for 10 seconds when the connected smartphone receives an SNS, E-mail or other notification. After that, the icon stays on until you turn the vehicle off.

FAU86842

Instrument and control functions

TIP

- This function works only when the smartphone is connected to the vehicle.
- Notifications must be setup for each application on the connected smartphone in advance.

EAUN2863

Yamaha Motorcycle Connect icon

This icon comes on when CCU and smartphone are connected via the Yamaha Motorcycle Connect app.

TIP _____

Even if the smartphone is not connected, when the vehicle is turned on, this icon should come on for a few seconds. Otherwise have a Yamaha dealer check the CCU and the electrical circuit.

FALIN2874

Smartphone battery level meter

This meter indicates the current battery level of the connected smartphone. The display segments of the meter disappear from full to blank as the battery

level decreases. When approximately 10% or less of the battery remains, the last segment starts flashing.

TIP

Even if the smartphone is not connected, when the vehicle is turned on, this icon should come on for a few seconds. Otherwise have a Yamaha dealer check the CCU and the electrical circuit.

Speedometer



1. Speedometer

The speedometer shows the vehicle's traveling speed.

Fuel meter



1. Fuel meter

EAU86831

The fuel meter indicates the amount of fuel in the fuel tank. The display segments of the fuel meter disappear from "F" (full) towards "E" (empty) as the fuel level decreases. When approximately 0.2 L (0.07 US gal, 0.06 Imp.gal) of fuel remains, the last segment starts flashing. Refuel as soon as possible.

TIP _____

If a problem is detected in the electrical circuit, the fuel level segments will flash repeatedly. If this occurs, have a Yamaha dealer check the vehicle.


FCAF0121

NOTICE

Do not let the vehicle run completely out of fuel. This may cause damage to the catalytic converter.

Multi-function display

EAUN4960



1. Multi-function display


The multi-function display is equipped with the following:

- an odometer (ODO)
- a tripmeter (TRIP)
- a clock
- a battery voltage display (BATT)

Push the "RES/SEL" button to change the display in the following order:

 $\begin{array}{c} \mathsf{ODO} \to \mathsf{TRIP} \to \mathsf{CLOCK} \to \mathsf{BATT} \to \\ \mathsf{ODO} \end{array}$

Odometer



1. Odometer


The odometer shows the total distance traveled by the vehicle.

TIF

The odometer will lock at "999999" and cannot be reset.

Tripmeter

EAU86891



EAUN4970

1. Tripmeter

The tripmeter shows the distance traveled since it was last reset.

To reset the tripmeter, set the display to the tripmeter, and then hold the "RES/SEL" button until it is reset.


TIP

The tripmeter will reset and continue counting after 9999.9 is reached.

FAUN5090

Instrument and control functions

Clock



1. Clock

The clock uses a 12-hour time system.

To set the clock


- 1. Use the "RES/SEL" button to change the display to the clock.
- 2. Hold the "RES/SEL" button until the hour digits start flashing.
- 3. Use the "RES/SEL" button to set the hours.
- 4. Hold the "RES/SEL" button until the minute digits start flashing.
- 5. Use the "RES/SEL" button to set the minutes.
- 6. Hold the "RES/SEL" button to confirm the settings.

TIP

EAUN4980

When CCU and smartphone is connected after vehicle power on, the clock is automatically adjusted.

Battery voltage display



1. Battery voltage meter


This display shows the current charge state of the battery.

- Over 12.8 V = Full charge.
- Under 12.4 V = Charging is required.

TIP

If the battery voltage is less than 9.0 V, "__." is displayed.

SMG "ASSIST" icon



1. SMG "ASSIST" icon

This vehicle is equipped with a Smart Motor Generator (SMG) that not only starts the engine, but also assists with initial acceleration.

When SMG is active, moving arrows will appear around the "ASSIST" icon.

TIP _____

EAUA3020

When battery voltage is low, the smart motor generator may not assist with acceleration.

"ECO" indicator



1. "ECO" indicator

This indicator comes on when the vehicle is being operated in an environmentally friendly, fuel-efficient manner. The indicator goes off when the vehicle is stopped.

TIP


Consider the following tips to reduce fuel consumption:

- Avoid high engine speeds during acceleration.
- Travel at a constant speed.
- Select the transmission gear that is appropriate for the vehicle speed.

Handlebar switches

Left


FAUN5100



- 1. Dimmer switch "≣○/ ▮○"
- 2. Turn signal switch "⟨□/□⟩"
- 3. Horn switch " "

EAU1234U

Right



- 1. Stop and Start System switch "A/A" (for equipped models)
- 2. Hazard lights switch "△/OFF" (for equipped models)
- 3. Start switch "(≶)"

EAU12402

Dimmer switch "≣○/ () "

Set this switch to "≣○" for the high beam and to "≣○" for the low beam.

EAU12461

Turn signal switch "⟨¬/¬⟩"

To signal a right-hand turn, push this switch to "⇒". To signal a left-hand turn, push this switch to "<>. When released, the switch returns to the center position. To cancel the turn signal lights, push the switch in after it has returned to the center position.

EAU12902

Instrument and control functions

FAU12501

Horn switch "►"

Press this switch to sound the horn.

EAU12722

Start switch "®"

With the sidestand up, push this switch while applying the front or rear brake to crank the engine with the starter. See page 7-2 for starting instructions prior to starting the engine.

FAUN4710

Hazard lights switch "△/OFF" (for equipped models)

With the main switch in the "ON" position, use this switch to turn on the hazard lights (simultaneous flashing of all turn signal lights).

The hazard lights are used in case of an emergency or to warn other drivers when your vehicle is stopped where it might be a traffic hazard.

ECA10062

NOTICE


Do not use the hazard lights for an extended length of time with the engine not running, otherwise the battery may discharge.

Stop and Start System switch "A/A" (for equipped models)

To turn on the Stop and Start System. set the switch to "A". To turn off the Stop and Start System, set this switch to "A".

FAU76391

Front brake lever



1. Front brake lever

The front brake lever is located on the right side of the handlebar. To apply the front brake, pull this lever toward the throttle grip.

EAU12952

Rear brake lever




1. Rear brake lever

The rear brake lever is located on the left side of the handlebar. To apply the rear brake, pull this lever toward the handlebar grip.

Rear brake lever lock

This vehicle is equipped with a rear brake lever lock.



- 1. Rear brake lever
- 2. Lever lock pin
- 3. Lever lock pin stopper

To lock the brake lever

- 1. Pull the rear brake lever toward the handlebar grip.
- 2. Push the lever lock pin down until it latches with the lever lock pin stopper.

To unlock the brake lever

1. Pull the brake lever toward the handlebar grip.

2. The lever lock pin should release from the lever lock pin stopper and unlock the rear brake lever.

TIP

EAUN0440

Use the rear brake lever lock while seated.

EWAN0010

MARNING

Never apply the rear brake lever lock while the vehicle is moving, otherwise loss of control or an accident may result. Make sure that the vehicle is stopped before applying the rear brake lever lock.

Fuel tank cap

EAU37474


To install the fuel tank cap



EAU13213

Make sure there is sufficient gasoline in the tank.

EWA10882



- 1. Fuel tank cap
- 2. Open.
- 3. Close.

To remove the fuel tank cap

- 1. Open the seat. (See page 5-16.)
- 2. Turn the fuel tank cap counterclockwise and pull it off.



- Insert the fuel tank cap into the tank opening and turn it clockwise until the "△" marks on the cap and tank cover are aligned.
- 2. Close the seat.

EWA11092


MARNING

Make sure that the fuel tank cap is properly closed after filling fuel. Leaking fuel is a fire hazard.

WARNING

Gasoline and gasoline vapors are extremely flammable. To avoid fires and explosions and to reduce the risk of injury when refueling, follow these instructions.

- 1. Before refueling, turn off the engine and be sure that no one is sitting on the vehicle. Never refuel while smoking, or while in the vicinity of sparks, open flames, or other sources of ignition such as the pilot lights of water heaters and clothes dryers.
- Do not overfill the fuel tank. Stop filling when the fuel reaches the bottom of the filler tube. Because fuel expands when it heats up, heat from the engine or the sun can cause fuel to spill out of the fuel tank.



ZAUU0026

- 1. Fuel tank filler tube
- 2. Maximum fuel level
- 3. Wipe up any spilled fuel immediately. *NOTICE:* Immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts. [ECA10072]
- 4. Be sure to securely close the fuel tank cap.

EWA15152

WARNING

Gasoline is poisonous and can cause injury or death. Handle gasoline with care. Never siphon gasoline by mouth. If you should swallow some gasoline or inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immedi-

ately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.

EAUN0750

Recommended fuel:

Unleaded gasoline only **Fuel tank capacity:**5.1 L (1.3 US gal, 1.1 Imp.gal)

ECA11401

NOTICE

Use only unleaded gasoline. The use of leaded gasoline will cause severe damage to internal engine parts, such as the valves and piston rings, as well as to the exhaust system.

Catalytic converter

The exhaust system contains catalytic converter(s) to reduce harmful exhaust emissions.

EWA10863

FAU13435

WARNING

The exhaust system is hot after operation. To prevent a fire hazard or burns:


- Do not park the vehicle near possible fire hazards such as grass or other materials that easily burn.
- Park the vehicle in a place where pedestrians or children are not likely to touch the hot exhaust system.
- Make sure that the exhaust system has cooled down before doing any maintenance work.
- Do not allow the engine to idle more than a few minutes. Long idling can cause a build-up of heat.

EAUU0373

Seat

To open the seat

- 1. Place the vehicle on the centerstand.
- 2. Insert the key into the main switch, and then turn it counterclockwise to "OPEN".



- 1. Seat lock
- 2. Seat

TIP_

Do not push inward when turning the key.

3. Fold the seat up.

To close the seat


- 1. Fold the seat down, and then push it down to lock it in place.
- 2. Remove the key from the main switch if the vehicle will be left unattended.

TIP

Make sure that the seat is properly secured before riding.

Helmet holders

EAU37482



1. Helmet holder

The helmet holders are located under the seat.

To secure a helmet to a helmet holder

- 1. Open the seat. (See page 5-16.)
- 2. Attach a helmet to a helmet holder, and then securely close the seat. WARNING! Never ride with a helmet attached to the helmet holder, since the helmet may hit objects, causing loss of control and possibly an accident. [EWA10162]

To release a helmet from a helmet holder

Open the seat, remove the helmet from the helmet holder, and then close the seat.

Storage compartments

Front storage compartment

The front storage compartment is located at the front of the vehicle. Use this compartment for small items.



1. Front storage compartment

EWA17250

WARNING

- Do not exceed the load limit of 0.5 kg (1.1 lb) for the front storage compartment.
- Do not place anything in the front storage compartment that will interfere with your operating the vehicle.

Rear storage compartment

The rear storage compartment is located under the seat. Use this compartment for large items. (See page 5-16.)



1. Rear storage compartment

EWAT1052

WARNING

- Do not exceed the load limit of 5 kg (11 lb) for the rear storage compartment.
- Do not exceed the maximum load of 158 kg (348 lb) for the vehicle.

ECA21150

NOTICE

Keep the following points in mind when using the storage compartment.

- Since the storage compartment accumulates heat when exposed to the sun and/or the engine heat, do not store anything susceptible to heat, consumables or flammable items inside it.
- To avoid humidity from spreading through the storage compartment, wrap wet articles in a plastic bag before storing them in the compartment.
- Since the storage compartment may get wet while the vehicle is being washed, wrap any articles stored in the compartment in a plastic bag.
- Do not keep anything valuable or breakable in the storage compartment.

TIP

Do not leave your vehicle unattended with the seat open.

Luggage hook

WARNING

- Do not exceed the load limit of 1 kg (2.2 lb) for the luggage hook.
- Do not exceed the maximum load of 158 kg (348 lb) for the vehicle.






1. Luggage hook

Power outlet

EWAT1032

This model is equipped with a 12V DC power outlet.



1. Power outlet

ECAN0140

FAUN2163

NOTICE

Do not use the power outlet when the engine is off, and do not exceed the specified electrical load; otherwise the fuse may blow or the battery may discharge.

When washing the vehicle, do not direct high-pressure washers at the power outlet area.

Maximum electrical load:


12 W (1A)

To use the power outlet

- 1. Turn the vehicle power off.
- 2. Remove the power outlet cap.
- 3. Turn the accessory off.
- 4. Insert the accessory plug into the power outlet.
- 5. Turn the vehicle power on and start the engine.
- 6. Turn the accessory on.

TIP

When finished riding, turn off the accessory and disconnect it from the power outlet, and then install the cap.



1. Power outlet cap

WARNING

To prevent electrical shock or shortcircuiting, install the cap when the power outlet is not in use.

FWAN0050

Sidestand

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the vehicle upright.

TIP

- The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See the following section for an explanation of the ignition circuit cut-off system.)
- When the sidestand is lowered, the Stop and Start System is deactivated.

EWA10242

FAU76780


MARNING

The vehicle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up (or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the respon-

sibility of raising the sidestand before starting off. Therefore, check this system regularly and have a Yamaha dealer repair it if it does not function properly.

Ignition circuit cut-off system

Check the operation of the sidestand switch according to the following procedure.



WARNING

- The vehicle must be placed on the centerstand during this inspection.
- If a malfunction is found, have the vehicle inspected before riding.

For your safety – pre-operation checks

EAU1559B

Inspect your vehicle each time you use it to make sure the vehicle is in safe operating condition. Always follow the inspection and maintenance procedures and schedules described in the Owner's Manual.

EWA11152

M WARNING

Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. Do not operate the vehicle if you find any problem. If a problem cannot be corrected by the procedures provided in this manual, have the vehicle inspected by a Yamaha dealer.

Before using this vehicle, check the following points:

ITEM	CHECKS	PAGE
Fuel	 Check fuel level in fuel tank. Refuel if necessary. Check fuel line for leakage. Check fuel tank overflow hose for obstructions, cracks or damage, and check hose connection. 	5-14
Engine oil	 Check oil level in engine. If necessary, add recommended oil to specified level. Check vehicle for oil leakage. 	8-12
Final transmission oil	Check vehicle for oil leakage.	8-14
Front brake	 Check operation. If soft or spongy, have Yamaha dealer bleed hydraulic system. Check brake pads for wear. Replace if necessary. Check fluid level in reservoir. If necessary, add specified brake fluid to specified level. Check hydraulic system for leakage. 	8-21, 8-22
Rear brake	 Check operation. Lubricate cable if necessary. Check lever free play. Adjust if necessary. 	8-21, 8-22

For your safety – pre-operation checks

ITEM	CHECKS	PAGE
Throttle grip	 Make sure that operation is smooth. Check throttle grip free play. If necessary, have Yamaha dealer adjust throttle grip free play and lubricate cable and grip housing. 	8-17, 8-24
Control cables	Make sure that operation is smooth.Lubricate if necessary.	8-24
Wheels and tires	 Check for damage. Check tire condition and tread depth. Check air pressure. Correct if necessary. 	8-18, 8-20
Brake levers	 Make sure that operation is smooth. Lubricate lever pivoting points if necessary. 	8-24
Centerstand, sidestand	Make sure that operation is smooth.Lubricate pivots if necessary.	8-25
Chassis fasteners	 Make sure that all nuts, bolts and screws are properly tightened. Tighten if necessary. 	_
Instruments, lights, signals and switches	Check operation. Correct if necessary.	_
Sidestand switch	 Check operation of ignition circuit cut-off system. If system is not working correctly, have Yamaha dealer check vehicle. 	5-19

EAU15952

Read the Owner's Manual carefully to become familiar with all controls. If there is a control or function you do not understand, ask your Yamaha dealer.

EWA10272

WARNING

Failure to familiarize yourself with the controls can lead to loss of control, which could cause an accident or injury. EAU16842

Engine break-in

There is never a more important period in the life of your engine than the period between 0 and 1600 km (1000 mi). For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1600 km (1000 mi). The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

EAUM2012

0-1000 km (0-600 mi)

Avoid prolonged operation above 1/3 throttle. *NOTICE:* After 1000 km (600 mi) of operation, be sure to replace the engine oil and final transmission oil. [ECA11662]

1000-1600 km (600-1000 mi)

Avoid prolonged operation above 1/2 throttle.

1600 km (1000 mi) and beyond

The vehicle can now be operated normally.

ECA10271

NOTICE

If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

EAU76790

Starting the engine

The sidestand must be up in order for the ignition circuit cut-off system to enable starting (see page 5-20).

EWAN0020

WARNING

Before starting the engine, make sure that the vehicle is placed on the centerstand.

ECA10251

NOTICE

See page 7-1 for engine break-in instructions prior to operating the vehicle for the first time.

To start the engine

- 1. Place the vehicle on the center-stand.
- 2. Turn the key to "ON".
- 3. Apply the front or rear brake.
- Push the start switch.
 Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 5 seconds on any one attempt.

5. When the engine starts, release the start switch.

If the engine does not start, try again with the throttle grip open 1/4 turn (10 mm).

TIP

- If the engine will not not start by pushing the start switch, try using the kickstarter.
- The engine starts by opening the throttle while the Stop and Start System activates.

ECA11043

NOTICE

For maximum engine life, never accelerate hard when the engine is cold!

EAUN0073

ECAN0072


NOTICE

Do not ride through deep water, otherwise the engine may be damaged. Avoid puddles because they may be deeper than expected.

FAU45093


Starting off

 While pulling the rear brake lever with your left hand and holding the grab bar with your right hand, push the scooter off the centerstand.



- 1. Grab bar
 - 2. Sit astride the seat, and then adjust the rear view mirrors.
- 3. Switch the turn signals on.
- 4. Check for oncoming traffic, and then slowly turn the throttle grip (on the right) in order to take off.
- 5. Switch the turn signals off.

Acceleration and deceleration



The speed can be adjusted by opening and closing the throttle. To increase the speed, turn the throttle grip in direction (a). To reduce the speed, turn the throttle grip in direction (b).

ECA12682

NOTICE

 Use the brake when stopping on an uphill slope. Holding the vehicle at a stop with throttle operation will cause the clutch to heat up, causing damage to the clutch. Do not rev the throttle unnecessarily, otherwise the malfunction indicator light (MIL)/engine trouble warning light may come on.

Braking

EWA10301

FAU16794

WARNING

- Avoid braking hard or suddenly (especially when leaning over to one side), otherwise the scooter may skid or overturn.
- Railroad crossings, streetcar rails, iron plates on road construction sites, and manhole covers become extremely slippery when wet. Therefore, slow down when approaching such areas and cross them with caution.
- Keep in mind that braking on a wet road is much more difficult.
- Ride slowly down a hill, as braking downhill can be very difficult.
- 1. Close the throttle completely.
- 2. Apply both front and rear brakes simultaneously while gradually increasing the pressure.

Tips for reducing fuel consumption

Fuel consumption depends largely on your riding style. Consider the following tips to reduce fuel consumption:

- Avoid high engine speeds during acceleration.
- Avoid high engine speeds with no load on the engine.
- Turn the engine off instead of letting it idle for an extended length of time (e.g., in traffic jams, at traffic lights or at railroad crossings).

EAU16821

Parking

When parking, turn the vehicle power off. After turning off the main switch, be sure to remove the key and take it with you.

EWA18840

FAU76803

WARNING

- Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them and be burned.
- Do not park on a slope or on soft ground, otherwise the vehicle may overturn, increasing the risk of a fuel leak and fire.
- Do not park near grass or other flammable materials which might catch fire.
- If the Stop and Start System is left turned on, the battery could become discharged and it may not be possible to restart the engine due to insufficient battery voltage.

EAU85230

Periodic maintenance and adjustment

FAU17246

Periodic inspection, adjustment, and lubrication will keep your vehicle in the safest and most efficient condition possible. Safety is an obligation of the vehicle owner/operator. The most important points of vehicle inspection, adjustment, and lubrication are explained on the following pages.

The intervals given in the periodic maintenance charts should be simply considered as a general guide under normal riding conditions. However, depending on the weather, terrain, geographical location, and individual use, the maintenance intervals may need to be shortened.

FWA10322

WARNING

Failure to properly maintain the vehicle or performing maintenance activities incorrectly may increase your risk of injury or death during service or while using the vehicle. If you are not familiar with vehicle service, have a Yamaha dealer perform service.

FWA15123

WARNING

Turn off the engine when performing maintenance unless otherwise specified.

- A running engine has moving parts that can catch on body parts or clothing and electrical parts that can cause shocks or fires.
- Running the engine while servicing can lead to eye injury, burns, fire, or carbon monoxide poisoning - possibly leading to death. See page 2-3 for more information about carbon monoxide.


EWA15461

WARNING

Brake discs, calipers, drums, and linings can become very hot during use. To avoid possible burns, let brake components cool before touching them.

Tool kit





1. Tool kit

The tool kit is in the location shown.

The information included in this manual and the tools provided in the tool kit are intended to assist you in the performance of preventive maintenance and minor repairs. However, a torque wrench and other tools are necessary to perform certain maintenance work correctly.

If you do not have the tools or experience required for a particular job, have your Yamaha dealer perform it for you.

TIP_

- The annual checks must be performed every year, except if a kilometer-based maintenance is performed instead.
- From 16000 km, repeat the maintenance intervals starting from 4000 km.
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

Periodic maintenance chart for the emission control system

FAU46932

				ODOMETER READING (whichever comes first)					
NO.		ITEM	CHECK OR MAINTENANCE JOB	1000 km or 1 month	4000 km or 4 months	7000 km or 7 months	10000 km or 10 months	13000 km or 13 months	ANNUAL CHECK
1	*	Fuel line	Check fuel hoses for cracks or damage.		V	$\sqrt{}$	V	\checkmark	$\sqrt{}$
2	*	Fuel filter	Check condition.Replace if necessary.		Every 12000 km (7500 mi)				
3		Spark plug	Check condition.Clean and regap.		$\sqrt{}$	$\sqrt{}$	$\sqrt{}$	\checkmark	$\sqrt{}$
			• Replace.	Every 6000 km (3500 mi)					
4	*	Valves	Check valve clearance.Adjust if necessary.			$\sqrt{}$		√	
5	*	Fuel injection	Adjust engine idling speed.		$\sqrt{}$	$\sqrt{}$	$\sqrt{}$	\checkmark	$\sqrt{}$
6	*	Exhaust system	Check for leakage.Tighten if necessary.Replace gasket(s) if necessary.		V	V	V	√	

EAUN0284

General maintenance and lubrication chart

				ODOMETER READING (which			ever comes	first)	
NO.		ITEM	CHECK OR MAINTENANCE JOB	1000 km or 1 month	4000 km or 4 months	7000 km or 7 months	10000 km or 10 months	13000 km or 13 months	ANNUAL CHECK
1	*	Diagnostic system check	 Perform dynamic inspection using Yamaha diagnostic tool. Check the error codes. 	V	√	V	V	V	V
2		Air filter element	Replace.			Every 15000	km (9000 mi)		
3		Air filter check hose	• Clean.	$\sqrt{}$	√	√	√	V	$\sqrt{}$
4	*	V-belt case air filter element	Clean.Replace if necessary.		√	√	V	V	$\sqrt{}$
5	*	Battery	Check voltage.Charge if necessary.	$\sqrt{}$	$\sqrt{}$	$\sqrt{}$	V	√	$\sqrt{}$
6	*	Front brake	Check operation, fluid level and vehicle for fluid leakage.	$\sqrt{}$	$\sqrt{}$	√	√	V	$\sqrt{}$
			Replace brake pads.	Whenever worn to the limit					
7	*	Rear brake	Check operation and adjust brake lever free play.	V	√	√	√	V	V
			Replace brake shoes.	Whenever worn to the limit					
8	*	Brake hoses	Check for cracks or damage.Check for correct routing and clamping.		√	V	V	V	V
			Replace.	Every 4 years					
9	*	Brake fluid	Change.	Every 2 years					
10	*	Wheels	Check runout and for damage.				√	V	$\sqrt{}$

				ODC	OMETER REA	NDING (which	ever comes	ever comes first)		
NO.		ITEM	CHECK OR MAINTENANCE JOB	1000 km or 1 month	4000 km or 4 months	7000 km or 7 months	10000 km or 10 months	13000 km or 13 months	ANNUAL CHECK	
11	*	Tires	 Check tread depth and for damage. Replace if necessary. Check air pressure. Correct if necessary. 		V	V	V	√	√	
12	*	Wheel bearings	Check bearings for looseness or damage.		V	V	V	$\sqrt{}$	$\sqrt{}$	
40	*	Steering bearings	Check bearing play and steering for roughness.	$\sqrt{}$	V	$\sqrt{}$	V	\checkmark	$\sqrt{}$	
13			Lubricate with lithium-soap- based grease.	Every 12000 km (7500 mi)						
14	*	Chassis fasteners	Make sure that all nuts, bolts and screws are properly tightened.		V	V	V	$\sqrt{}$	$\sqrt{}$	
15		Front brake lever pivot shaft	Lubricate with silicone grease.		V	√	V	V	V	
16		Rear brake lever pivot shaft	Lubricate with lithium-soap- based grease.		V	V	V	V	V	
17		Sidestand, center- stand	Check operation.Lubricate with lithium-soap- based grease.		√	V	V	√	V	
18	*	Sidestand switch	Check operation.	$\sqrt{}$	$\sqrt{}$	√	V	V	$\sqrt{}$	
19	*	Front fork	Check operation and for oil leakage.		V	V	V	√	$\sqrt{}$	
20	*	Shock absorber assemblies	Check operation and shock absorbers for oil leakage.		V	√	V	V	V	

			CHECK OR MAINTENANCE JOB	ODOMETER READING (whichever comes first)						
NO	Э.	ITEM		1000 km or 1 month	4000 km or 4 months	7000 km or 7 months	10000 km or 10 months	13000 km or 13 months	ANNUAL CHECK	
21		Engine oil	Change.Check oil level and vehicle for oil leakage.	V	V	V	V	V		
22	*	Engine oil strainer	• Clean.	$\sqrt{}$					$\sqrt{}$	
2		Final transmission	Check vehicle for oil leakage.	$\sqrt{}$	√	$\sqrt{}$	\checkmark	$\sqrt{}$		
23	oi	oil	• Change.	$\sqrt{}$	√ Every 12000 km (7500 mi)					
4	*	* V-belt	Check for damage and wear.			√	$\sqrt{}$	V	$\sqrt{}$	
24			• Replace.	Every 25000 km (15500 mi)						
25	*	V-belt secondary sheave	• Lubricate.	Every 12000 km (7500 mi)						
26	*	Front and rear brake switches	Check operation.	\checkmark	√	√	V	V	\checkmark	
27		Moving parts and cables	• Lubricate.		V	√	$\sqrt{}$	√	$\sqrt{}$	
28	*	Throttle grip	 Check operation. Check throttle grip free play, and adjust if necessary. Lubricate cable and grip housing. 		V	√	V	7	√	
29	*	Lights, signals and switches	Check operation.Adjust headlight beam.	V	√		V	V	√	

FAU73040

TIP_

- Air filter
 - This model's air filter is equipped with a disposable oil-coated paper element, which must not be cleaned with compressed air to avoid damaging it.
 - The air filter element needs to be replaced more frequently when riding in unusually wet or dusty areas.
- V-belt case air filter
 - The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- V-belt
 - The V-belt should be checked at the initial 7000 km (4500 mi) and every 3000 km (2000 mi) thereafter. Replace the V-belt if any damage or excessive wear is found. The V-belt needs to be replaced every 25000 km (16000 mi) even if there is no wear or damage.
- Hydraulic brake service
 - Regularly check and, if necessary, correct the brake fluid level. After dissembling the brake master cylinders and calipers, always change the brake fluid.
 - Every two years replace the internal components of the brake master cylinder and caliper, and change the brake fluid.
 - Replace the brake hose every four years or if cracked or damaged.
- Fuel system service
 - Use only unleaded gasoline. The use of leaded gasoline will cause severe damage to internal engine parts, such as the valves and piston rings, as well as to the exhaust system.
 - Replace the fuel filler cover every two years or if cracked or damaged.
 - Check the fuel filter for clogging or damage every 12000 km (7500 mi).
- Battery service
 - Check the condition and service the battery every 3 months.
 - Recharge the battery immediately if the voltage is less than 12.4 V.
 - If the battery tends to discharge, replace it immediately.

• If the vehicle will not be used for more than one month, remove the battery, fully charge it, and then store it in a cool, dry place.

FAU11877

Removing and installing panels

The panels shown need to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time a panel needs to be removed and installed.




- 1. Panel B (with headlight)
- 2. Panel A
- 3. Panel C
- 4. Panel D
- 5. Panel E

Panel A

To remove the panel


Remove the screws from panel A, and then pull the panel off.



- 1. Panel A
- 2. Screw

To install the panel

1. Place the panel in the original position, with the panel projections fitting into the holes.



- 1. Panel A
- 2. Projection
- 3. Hole


EAUN5000

2. Install the screws to the panel.

Panel B (with headlight)

To remove the panel

- 1. Remove panel A.
- 2. Remove the screws, bolts and quick fasteners, then pull panel B (with headlight) off.



- 1. Panel B (with headlight)
- 2. Screw
- 3. Bolt
- 4. Quick fastener


To install the panel

- 1. Place the panel in the original position, and then install the screws, bolts and quick fasteners.
- 2. Install panel A.

Panel C

To remove the panel

Remove the screws from panel C, and then pull the panel off.



- 1. Panel C
- 2. Screw


To install the panel

Place the panel in the original position, and then install the screws to the panel.

Panel D

To remove the panel

- 1. Open the seat. (See page 5-16.)
- 2. Remove panel C.
- 3. Remove the screws from panel D and then pull the panel off.



- 1. Panel D
- 2. Screw


To install the panel

- 1. Place the panel in the original position, and then install the screws.
- 2. Install panel C.
- 3. Close the seat.

Panel E

To remove the panel

- 1. Open the seat. (See page 5-16.)
- 2. Remove the screws and then pull panel E off.



- 1. Panel E
- 2. Screw

To install the panel


- 1. Place the panel in the original position, and then install the screws.
- 2. Close the seat.

Checking the spark plug

The spark plug is an important engine component, which is easy to check. Since heat and deposits will cause any spark plug to slowly erode, the spark plug should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plug can reveal the condition of the engine.


To remove the spark plug

- 1. Remove panel D. (See page 8-9.)
- 2. Remove the spark plug cap.



- 1. Spark plug cap
- 3. Remove the spark plug as shown, with a spark plug wrench available at a Yamaha dealer.





1. Spark plug wrench

To check the spark plug

1. Check that the porcelain insulator around the center electrode of the spark plug is a medium-to-light tan (the ideal color when the vehicle is ridden normally).


TIP

If the spark plug shows a distinctly different color, the engine could be operating improperly. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the vehicle.

Check the spark plug for electrode erosion and excessive carbon or other deposits, and replace it if necessary.

Specified spark plug: NGK/CR6HSA

 Measure the spark plug gap with a wire thickness gauge and, if necessary, adjust the gap to specification.



1. Spark plug gap

Spark plug gap:

0.6-0.7 mm (0.024-0.028 in)

To install the spark plug

- 1. Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.
- 2. Install the spark plug with the spark plug wrench, and then tighten it to the specified torque.

Tightening torque:


Spark plug:

13 N·m (1.3 kgf·m, 9.6 lb·ft)

TIP

If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

3. Install the spark plug cap.



- 1. Spark plug cap
- 2. Spark plug lead
 - 4. Install the panel D.

FAU62847

Engine oil and oil strainer

The engine oil level should be checked before each ride. In addition, the oil must be changed and the oil strainer cleaned at the intervals specified in the periodic maintenance and lubrication chart.

To check the engine oil level

- 1. Place the vehicle on the centerstand. A slight tilt to the side can result in a false reading.
- 2. Start the engine, warm it up for several minutes, and then turn it off.
- 3. Wait a few minutes until the oil settles, remove the oil filler cap, wipe the dipstick clean, insert it back into the oil filler hole (without screwing it in), and then remove it again to check the oil level.


EWAU0031

WARNING

The muffler and muffler protector become very hot during use. To avoid possible burns, let the muffler and protector cool before removing the oil filler cap.

TIP

The engine oil should be between the tip of the dipstick and maximum level mark.




- 1. Engine oil filler cap
- 2. O-ring
- 3. Engine oil dipstick
- 4. Maximum level mark
- 5. Tip of the engine oil dipstick
- 4. If the engine oil is at or below the minimum level mark, add sufficient oil of the recommended type to raise it to the correct level.
- 5. Insert the dipstick into the oil filler hole, and then tighten the oil filler cap.

To change the engine oil and clean the oil strainer

- 1. Start the engine, warm it up for several minutes, and then turn it off.
- 2. Place an oil pan under the engine to collect the used oil.
- 3. Remove the engine oil filler cap and drain bolt B to drain the oil from the crankcase. *NOTICE:* When removing the engine oil drain bolt, the O-ring, compression spring, and oil strainer will fall out. Take care not to lose these parts. IECA110021

FCA24060

Periodic maintenance and adjustment



- 1. Engine oil drain bolt A
- 2. Gasket
- 3. Oil strainer
- 4. Compression spring
- 5. O-ring
- 6. Engine oil drain bolt B

TIP

When only changing the engine oil, remove drain bolt A. When changing the engine oil and cleaning the engine oil strainer, remove drain bolt B also.

4. Clean the engine oil strainer with solvent, and then check it for damage and replace it if necessary.

5. Install the engine oil strainer, compression spring, engine oil drain bolt with new O-ring, and then tighten the drain bolt to the specified torque.

TIP

Make sure that the O-ring is properly seated.

Tightening torque:

Engine oil drain bolt A: 20 N·m (2.0 kgf·m, 15 lb·ft) Engine oil drain bolt B: 20 N·m (2.0 kgf·m, 15 lb·ft)

6. Refill with the specified amount of the recommended engine oil, and then install and tighten the oil filler cap.

Recommended engine oil:

See page 10-1.

Oil quantity:

0.80 L (0.85 US at, 0.70 Imp.at)

TIP_

Be sure to wipe off spilled oil on any parts after the engine and exhaust system have cooled down.

NOTICE

Make sure that no foreign material enters the crankcase.


- 7. Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.
- 8. Turn the engine off, and then check the oil level and correct it if necessary.

FAU67822


Final transmission oil

The final transmission case must be checked for oil leakage before each ride. If any leakage is found, have a Yamaha dealer check and repair your motorcycle. In addition, the final transmission oil must be changed as follows at the intervals specified in the periodic maintenance and lubrication chart.

- 1. Start the engine and warm up the final transmission oil by riding the motorcycle for several minutes.
- 2. Stop the engine and then place the motorcycle on the center-stand.
- 3. Place an oil pan under the final transmission case to collect the used oil.
- 4. Remove the final transmission oil filler cap and its O-ring from the final transmission case.



- 1. Final transmission oil filler cap
- 2. O-ring
- 5. Remove the final transmission oil drain bolt and its gasket to drain the oil from the final transmission case.



- 1. Final transmission oil drain bolt
- 2. Gasket

6. Install the final transmission oil drain bolt and its new gasket, and then tighten the bolt to the specified torque.

TIP

- Before installing the final transmission oil drain bolt and gasket, apply oil to them.
- Wipe off any excess oil afterwards.

Tightening torque:

Final transmission oil drain bolt: 20 N·m (2.0 kgf·m, 15 lb·ft)

7. Refill with the specified amount of the recommended final transmission oil. WARNING! Make sure that no foreign material enters the final transmission case. Make sure that no oil gets on the tire or wheel. [EWA11312]

Recommended final transmission oil:

See page 10-1.

Oil quantity:


0.10 L (0.11 US qt, 0.09 Imp.qt)

- 8. Install the final transmission oil filler cap and its new O-ring, and then tighten the oil filler cap.
- 9. Check the final transmission case for oil leakage. If oil is leaking, check for the cause.

Air filter and V-belt case air filter elements

The air filter element should be replaced and the V-belt case air filter element should be cleaned at the intervals specified in the periodic maintenance and lubrication chart. Service the air filter elements more frequently if you are riding in unusually wet or dusty areas. The air filter check hose and V-belt case air filter check hose must be frequently checked and cleaned if necessary.

Cleaning the air filter check hose



1. Air filter check hose


- Check the hose on the rear side of the air filter case for accumulated dirt or water.
- 2. If dirt or water is visible, remove the hose from the clamp, clean it, and then install it.

TIP _____

If dirt or water was found in the check hose, be sure to check the air filter element for excessive dirt or damage and replace it if necessary.


Replacing the air filter element

- 1. Place the vehicle on the centerstand.
- 2. Remove the air filter case cover by removing the screws.



- 1. Air filter case cover
- 2. Screw

3. Pull the air filter element out.



- 1. Air filter element
- 4. Insert a new air filter element into the air filter case. NOTICE: Make sure that the air filter element is properly seated in the air filter case. The engine should never be operated without the air filter element installed, otherwise the piston(s) and/or cylinder(s) may become excessively worn.

[ECA10482]


ECA21220

NOTICE

 The air filter element must be replaced at the intervals specified in the periodic maintenance chart.

- The air filter element should be replaced more frequently if you often ride in the rain or dusty areas.
- The air filter cannot be cleaned by blowing it with compressed air. It must be replaced.
- 5. Install the air filter case cover by installing the screws.

Cleaning the V-belt case check hose




- 1. V-belt case check hose
 - Check the hose on the rear side of the V-belt case for accumulated dirt or water.
- 2. If dirt or water is visible, remove the hose from the clamp, clean it, and then install it.

TIP

If dirt or water was found in the check hose, be sure to check the V-belt case air filter element for excessive dirt or damage and clean or replace it if necessary.


Cleaning the V-belt case air filter element

- 1. Place the vehicle on the center-stand.
- 2. Remove the bolts, and then pull the V-belt case air filter element cover outward and away from the V-belt case.



- 1. V-belt case air filter element cover
- 2. Bolt

3. Pull the V-belt case air filter element out, and then clean it with solvent. After cleaning, remove the remaining solvent by squeezing the element. WARNING! Use only a dedicated parts cleaning solvent. To avoid the risk of fire or explosion, do not use gasoline or solvents with a low flash point. [EWA10432] NOTICE: To avoid damaging the air filter element, handle it gently and carefully, and do not twist it. [ECA10522]



1. V-belt case air filter element



4. Apply oil of the recommended type to the entire surface of the sponge material, and then squeeze the excess oil out.

TIP

- The air filter element should be wet but not dripping.
- Check the air filter element for excessive dirt or damage and replace it if necessary.

Recommended oil:


Yamaha foam air filter oil or other quality foam air filter oil

- 5. Insert the element into the V-belt case.
- 6. Install the air filter element cover by installing the bolts.

EAU21386

Checking the throttle grip free play

Measure the throttle grip free play as shown.



1. Throttle grip free play

Throttle grip free play:

3.0-7.0 mm (0.12-0.28 in)

Periodically check the throttle grip free play and, if necessary, have a Yamaha dealer adjust it.

FAU21403

Valve clearance

The valves are an important engine component, and since valve clearance changes with use, they must be checked and adjusted at the intervals specified in the periodic maintenance chart. Unadjusted valves can result in improper air-fuel mixture, engine noise, and eventually engine damage. To prevent this from occurring, have your Yamaha dealer check and adjust the valve clearance at regular intervals.

TIP

This service must be performed when the engine is cold.

Tires

Tires are the only contact between the vehicle and the road. Safety in all conditions of riding depends on a relatively small area of road contact. Therefore, it is essential to maintain the tires in good condition at all times and replace them at the appropriate time with the specified tires.

Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

EWA10504

WARNING

Operation of this vehicle with improper tire pressure may cause severe injury or death from loss of control.

- The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).
- The tire air pressure must be adjusted in accordance with the riding speed and with the total

EAU82721

weight of rider, passenger, cargo, and accessories approved for this model.

Cold tire air pressure:

1 person:

Front:

150 kPa (1.50 kgf/cm², 22 psi)

Rear:

225 kPa (2.25 kgf/cm², 33 psi)

2 persons:

Front:

150 kPa (1.50 kgf/cm², 22 psi)

Rear:

225 kPa (2.25 kgf/cm², 33 psi)

Maximum load:

Vehicle:

158 kg (348 lb)

The vehicle's maximum load is the combined weight of the rider, passenger, cargo, and any accessories.


EWA10512



Never overload your vehicle. Operation of an overloaded vehicle could cause an accident.

EWA10583

Tire inspection



- 1. Tire sidewall
- 2. Tire wear indicator
- 3. Tire tread depth

The tires must be checked before each ride. If a tire tread shows crosswise lines (minimum tread depth), if the tire has a nail or glass fragments in it, or if the sidewall is cracked, contact a Yamaha dealer immediately and have the tire replaced.

Minimum tire tread depth (front and rear):

1.0 mm (0.04 in)

WARNING

- It is dangerous to ride with a worn-out tire. When a tire tread begins to show crosswise lines, have a Yamaha dealer replace the tire immediately.
- The replacement of all wheel and brake-related parts, including the tires, should be left to a Yamaha dealer, who has the necessary professional knowledge and experience to do so.
- Ride at moderate speeds after changing a tire since the tire surface must first be "broken in" for it to develop its optimal characteristics.

Tire information

This model is equipped with tubeless tires and tire air valves.

Tires age, even if they have not been used or have only been used occasionally. Cracking of the tread and sidewall rubber, sometimes accompanied by carcass deformation, is an evidence of

ageing. Old and aged tires shall be checked by tire specialists to ascertain their suitability for further use.

EWA10462

MARNING

The front and rear tires should be of the same make and design, otherwise the handling characteristics of the vehicle may be different, which could lead to an accident.

After extensive tests, only the tires listed below have been approved for this model by Yamaha.

Front tire:

Size:

110/70-12 47L

Manufacturer/model: MAXXIS/M6219Y

Rear tire:

Size:

110/70-12 47L Manufacturer/model: MAXXIS/M6220

FAU21963


Cast wheels

To maximize the performance, durability, and safe operation of your vehicle, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends, warpage or other damage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.

E

Checking the front brake lever free play



1. No brake lever free play

There should be no free play at the brake lever end. If there is free play, have a Yamaha dealer inspect the brake system.

EWA14212

WARNING


A soft or spongy feeling in the brake lever can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the vehicle. Air in the hydraulic system will diminish the

braking performance, which may result in loss of control and an accident.

FAI 12217

Adjusting the rear brake lever free play

Measure the rear brake lever free play as shown.




1. Rear brake lever free play

Rear brake lever free play:

10.0-20.0 mm (0.39-0.79 in)

Periodically check the brake lever free play and, if necessary, adjust it as follows.

To increase the brake lever free play, turn the adjusting nut at the brake shoe plate in direction (a). To decrease the brake lever free play, turn the adjusting nut in direction (b).



1. Rear brake lever free play adjusting nut

EWA10651

MARNING

If proper adjustment cannot be obtained as described, have a Yamaha dealer make this adjustment.


FAU22382

Checking the front brake pads and rear brake shoes

The front brake pads and the rear brake shoes must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart.

EAU22434

Front brake pads




1. Brake pad wear indicator groove

Each front brake pad is provided with wear indicator grooves, which allow you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator grooves. If a brake pad has worn to the point that the wear

indicator grooves have almost disappeared, have a Yamaha dealer replace the brake pads as a set.

EAU22541

Rear brake shoes




- 1. Brake shoe wear indicator
- 2. Brake shoe wear limit line

The rear brake is provided with a wear indicator, which allows you to check the brake shoe wear without having to disassemble the brake. To check the brake shoe wear, check the position of the wear indicator while applying the brake. If a brake shoe has worn to the point that the wear indicator reaches the wear limit line, have a Yamaha dealer replace the brake shoes as a set.

Checking the brake fluid level

Before riding, check that the brake fluid is above the minimum level mark. Check the brake fluid level with the top of the reservoir level. Replenish the brake fluid if necessary.



1. Minimum level mark

Specified brake fluid: DOT 3 or DOT 4

EWA15981

FAU37004

WARNING

Improper maintenance can result in loss of braking ability. Observe these precautions:

- Insufficient brake fluid may allow air to enter the brake system, reducing braking performance.
- Clean the filler cap before removing. Use only DOT 3 or DOT 4 brake fluid from a sealed container.
- Use only the specified brake fluid; otherwise, the rubber seals may deteriorate, causing leakage.
- Refill with the same type of brake fluid. Adding a brake fluid other than DOT 3 or DOT 4 may result in a harmful chemical reaction.
- Be careful that water does not enter the brake fluid reservoir when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.

ECA17641

NOTICE

Brake fluid may damage painted surfaces or plastic parts. Always clean up spilled fluid immediately.

EAUU0311

Periodic maintenance and adjustment

As the brake pads wear, it is normal for the brake fluid level to gradually go down. A low brake fluid level may indicate worn brake pads and/or brake system leakage; therefore, be sure to check the brake pads for wear and the brake system for leakage. If the brake fluid level goes down suddenly, have a Yamaha dealer check the cause before further ridina.

Changing the brake fluid

Have a Yamaha dealer change the brake fluid at the intervals specified in the periodic maintenance and lubrication chart. In addition, have the oil seals of the brake master cylinder and caliper as well as the brake hose replaced at the intervals listed below or whenever they are damaged or leaking.

- Brake seals: Replace every two years.
- Brake hose: Replace every four years.

Checking the V-belt

The V-belt must be checked and replaced by a Yamaha dealer at the interspecified in the vals periodic maintenance and lubrication chart.

FAU23098

Checking and lubricating the cables

The operation of all control cables and the condition of the cables should be checked before each ride, and the cables and cable ends should be lubricated if necessary. If a cable is damaged or does not move smoothly, have a Yamaha dealer check or replace it. WARNING! Damage to the outer housing of cables may result in internal rusting and cause interference with cable movement. Replace damaged cables as soon as possible to prevent unsafe conditions. [EWA10712]

Recommended lubricant:

Yamaha cable lubricant or other suitable cable lubricant

EAU49

Checking and lubricating the throttle grip and cable


The operation of the throttle grip should be checked before each ride. In addition, the cable should be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance chart.

EAU43643

Lubricating the front and rear brake levers

The pivoting points of the front and rear brake levers must be lubricated at the intervals specified in the periodic maintenance and lubrication chart.

Front brake lever




Rear brake lever



Recommended lubricants:

Front brake lever:
Silicone grease
Rear brake lever:
Lithium-soap-based grease

Checking and lubricating the centerstand and sidestand



- 1. Sidestand
- 2. Centerstand

The operation of the centerstand and sidestand should be checked before each ride, and the pivots and metal-to-metal contact surfaces should be lubricated if necessary.

EWA10742

WARNING

If the centerstand or sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it. Otherwise, the centerstand or sidestand could contact the ground and distract the operator, resulting in a possible loss of control. **Recommended lubricant:**

Lithium-soap-based grease

FAU23273

Checking the front fork

The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

To check the condition

Check the inner tubes for scratches, damage and excessive oil leakage.

To check the operation

- 1. Place the vehicle on a level surface and hold it in an upright position. WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over. [EWA10752]
- 2. While applying the front brake, push down hard on the handle-bars several times to check if the front fork compresses and rebounds smoothly.



NOTICE


If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.

ECA10591

Checking the steering


Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

- 1. Place the vehicle on the centerstand. WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over. IEWA107521
- Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.




FAUN3531

Checking the wheel bearings



The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.

Battery



- 1. Battery
- 2. Negative battery lead (black)
- 3. Positive battery lead (red)

The battery is located under the footboard.

This model is equipped with a VRLA (Valve Regulated Lead Acid) battery. There is no need to check the electrolyte or to add distilled water. However. the battery lead connections need to be checked and, if necessary, tightened.

EWA10761

WARNING


 Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.

- EXTERNAL: Flush with plenty of water.
- INTERNAL: Drink large quantities of water or milk and immediately call a physician.
- EYES: Flush with water for 15 minutes and seek prompt medical attention.
- Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.
- **KEEP THIS AND ALL BATTER-**IES OUT OF THE REACH OF CHILDREN.

To access the battery

1. Remove the panel C. (See page 8-8.)

2. Remove the battery cover by pulling it upward.



- 1. Battery cover
- 2. Screw

To charge the battery

Have a Yamaha dealer charge the battery as soon as possible if it seems to have discharged. Keep in mind that the battery tends to discharge more quickly if the vehicle is equipped with optional electrical accessories.

ECA16522

NOTICE

To charge a VRLA (Valve Regulated Lead Acid) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery.

To store the battery

- 1. If the vehicle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place. NOTICE: When removing the battery, be sure to turn the main switch off, then disconnect the negative lead before disconnecting the positive lead. [ECA16304]
- 2. If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.
- 3. Fully charge the battery before installation. *NOTICE:* When installing the battery, be sure to turn the main switch off, then connect the positive lead before connecting the negative lead.

[ECA16842]

4. After installation, make sure that the battery leads are properly connected to the battery terminals.

NOTICE

Always keep the battery charged. Storing a discharged battery can cause permanent battery damage.


ECA16531

Replacing the fuses

The fuse box, which contains the fuses for the individual circuits, is located behind panel D. (See page 8-8.)



1. Fuse box



- 1. Signaling system fuse 1
- 2. Main fuse

FAUN3540

- 3. Signaling system fuse 2
- 4. Backup fuse
- 5. Terminal fuse
- 6. Spare fuse

If a fuse is blown, replace it as follows.

- 1. Turn off the electrical circuit in question, and then turn off the main switch.
- 2. Remove panel D. (See page 8-8.)
- 3. Remove the blown fuse, and then install a new fuse of the specified amperage. WARNING! Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire. [EWA15132]

Specified fuses:

Main fuse:

20.0 A

Signaling system fuse 1:

7.5 A

Signaling system fuse 2:

7.5 A

Terminal fuse:

5.0 A

Backup fuse:

7.5 A

4. Turn the main switch on, and then turn on the electrical circuit in question to check if the device operates.

TIP


If the fuse immediately blows again, have a Yamaha dealer check the electrical system.

5. Install panel D by installing the screws.

FAUF3890

Vehicle lights

This model is equipped with LED lights for headlight and auxiliary lights. If a light does not come on, check the fuse and then have a Yamaha dealer check the vehicle.



- 1. Headlight (high beam)
- 2. Headlight (low beam)
- 3. Auxiliary light

ECA16581

NOTICE

Do not affix any type of tinted film or stickers to the headlight lens.

Replacing a front turn signal light bulb

If a front turn signal light bulb burns out, replace it as follows.

ECA10671

NOTICE

It is advisable to have a Yamaha dealer perform this job.

- 1. Place the motorcycle on the centerstand.
- 2. Remove panel A and B. (See page 8-8.)
- 3. Remove the socket (together with the bulb) by turning it counter-clockwise.



- 1. Turn signal light bulb socket
- 4. Remove the burnt out bulb by pulling it out.

5. Insert a new bulb into the socket.

ECAU008

NOTICE

If a turn signal light bulb of different wattage than recommended is used, the turn signal light flashing may be affected.

- 6. Install the socket (together with the bulb) by turning it clockwise.
- 7. Install the panels.

EAUN5020

Replacing a tail/brake light bulb or a rear turn signal light bulb

If a tail/brake light bulb or a rear turn signal light bulb burns out, replace it as follows.


ECA10671

NOTICE


It is advisable to have a Yamaha dealer perform this job.

Tail/brake light bulb

- 1. Remove panel E. (See page 8-8.)
- 2. Remove the fuel tank cover by removing the quick fasteners and fuel tank cap.



- 1. Fuel tank cover
- 2. Quick fastener
- 3. Fuel tank cap
 - 3. Remove the bulb socket (together with the bulb) by turning it counterclockwise and pulling the taillight bulb socket up at an angle.



1. Tail/brake light bulb socket

- 4. Remove the burnt-out bulb by pushing it in and turning it counterclockwise.
- 5. Insert a new bulb into the socket by pushing it in and turn it clockwise until it stops.

ECAU0091


NOTICE

If a taillight bulb of different wattage than recommended is used, it may cause the battery to discharge or affect the taillight lighting.

- 6. Install the bulb socket (together with the bulb) by turning it clockwise.
- 7. Install the fuel tank cover.
- 8. Install the fuel tank cap.
- 9. Install the panel.

Rear turn signal light bulb

- 1. Remove panel E. (See page 8-8.)
- 2. Remove the fuel tank cover by removing the quick fasteners and fuel tank cap. (See page 5-14.)
- 3. Remove the bulb socket (together with the bulb) by turning it counterclockwise.



- 1. Rear turn signal light bulb socket
- 4. Remove the burnt-out bulb from the socket by pulling it out.
- 5. Insert a new bulb into the socket.

ECAU0081

NOTICE

If a turn signal light bulb of different wattage than recommended is used, the turn signal light flashing may be affected.

- Install the bulb socket (together with the bulb) by pushing it inward.
- 7. Install the fuel tank cover.
- 8. Install the fuel tank cap.
- 9. Install the panel.

Troubleshooting

Although Yamaha vehicles receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting charts represent quick and easy procedures for checking these vital systems yourself. However, should your vehicle require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the vehicle properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

EWA15142

EAU60701

WARNING

When checking the fuel system, do not smoke, and make sure there are no open flames or sparks in the area, including pilot lights from water heaters or furnaces. Gasoline or gasoline vapors can ignite or explode, causing severe injury or property damage.

FAU76843

Stop and Start System trouble-shooting (for equipped models)

If a problem occurs, check the following before taking the vehicle to a Yamaha dealer.

The Stop and Start System indicator light does not come on.

- 1. Is the main switch turned on?
- 2. Is the Stop and Start System switch set to "A"?
- 3. Was the engine warmed up sufficiently after starting?
- 4. After the engine was warmed up, was the engine left idling for a certain period of time?
- 5. Did the vehicle travel at a speed of 10 km/h or higher?

Even if the preceding conditions are met, the Stop and Start System may not activate in order to preserve battery power. In this case, continue to drive the vehicle.

In addition, the Stop and Start System indicator light does not come on if the engine trouble warning light is on.

If the Stop and Start System indicator light still does not come on after you checked the preceding conditions, have a Yamaha dealer check the vehicle as soon as possible.

The Stop and Start System indicator light comes on, but the engine does not stop automatically.

- Was the vehicle stopped completely?
 The engine may not stop automatically until the vehicle is stopped for a certain period of time. Try bringing the vehicle to a complete stop.
- Is the throttle grip turned?
 The engine does not stop automatically if the throttle grip is not in the fully closed position.
 Turn the throttle grip to the fully closed position.

If the engine still does not stop automatically after you checked the preceding conditions, have a Yamaha dealer check the vehicle as soon as possible.

After the engine was stopped by the Stop and Start System, the engine does not restart even if the throttle grip is turned.

- 1. Is the Stop and Start System switch set to "A"?


 If the Stop and Start System switch is set to "A" while the Stop and Start System is activated, the Stop and Start System will be turned off.
- Was the sidestand operated?
 When the sidestand is lowered, the Stop and Start System is deactivated.
- 3. Was the engine left stopped by the Stop and Start System for a long period of time?

 If the engine is left stopped by the Stop and Start System for a long period of time, the battery could become discharged.

If the engine still does not restart after you checked the preceding conditions, have a Yamaha dealer check the vehicle as soon as possible.

Troubleshooting chart

EAU86350



Scooter care and storage

Matte color caution

EAU37834

ECA15193

NOTICE

Some models are equipped with matte colored finished parts. Be sure to consult a Yamaha dealer for advice on what products to use before cleaning the vehicle. Using a brush, harsh chemical products or cleaning compounds when cleaning these parts will scratch or damage their surface. Wax also should not be applied to any matte colored finished parts.

Care

Frequent, thorough cleaning of the vehicle will not only enhance its appearance but also will improve its general performance and extend the useful life of many components. Washing, cleaning, and polishing will also give you a chance to inspect the condition of the vehicle more frequently. Be sure to wash the vehicle after riding in the rain or near the sea, because salt is corrosive to metals.

TIP

See your Yamaha dealer for additional cleaning tips.

ECA26280

NOTICE

Improper cleaning can cause cosmetic and mechanical damage. Do not use:

 high-pressure washers or steam-jet cleaners. Excessive water pressure may cause water seepage and deterioration of wheel bearings, brakes, transmission seals and electrical devices. Avoid high-pressure

EAUN2631

- detergent applications such as those available in coin-operated car washers.
- harsh chemicals, including strong acidic wheel cleaners, especially on spoke or magnesium wheels.
- harsh chemicals, abrasive cleaning compounds, or wax on matte-finished parts. Brushes can scratch and damage the matte-finish, use soft sponge or towel only.
- towels, sponges, or brushes contaminated with abrasive cleaning products or strong chemicals such as, solvents, gasoline, rust removers, brake fluid, or antifreeze, etc.

Before washing

- 1. Park the vehicle out of direct sunlight and allow it to cool. This will help avoid water spots.
- 2. Make sure all caps, covers, electrical couplers and connectors are tightly installed.
- 3. Cover the muffler end with a plastic bag and a strong rubber band.

Scooter care and storage

- 4. Pre-soak stubborn stains like insects or bird droppings with a wet towel for a few minutes.
- Remove road grime and oil stains with a quality degreasing agent and a plastic-bristle brush or sponge. NOTICE: Do not use degreasing agent on areas requiring lubrication such as seals, gaskets, and wheel axles. Follow product instructions.

[ECA26290]

Washing

- Rinse off any degreaser and spray down the vehicle with a garden hose. Use only enough pressure to do the job. Avoid spraying water directly into the muffler, instrument panel, air inlet, or other inner areas such as underseat storage compartments.
- 2. Wash the vehicle with a quality automotive-type detergent mixed with cool water and a soft, clean towel or sponge. Use an old toothbrush or plastic-bristle brush for hard-to-reach places. **NOTICE:**Use cold water if the vehicle has

- been exposed to salt. Warm water will increase salt's corrosive properties. [ECA26301]
- 3. For windshield-equipped vehicles: Clean the windshield with a soft towel or sponge dampened with water and a pH neutral detergent. If necessary, use a high-quality windshield cleaner or polish for motorcycles. *NOTICE:* Never use any strong chemicals to clean the windshield. Additionally, some cleaning compounds for plastic may scratch the windshield, so be sure to test all cleaning products before general application. [ECA26310]
- 4. Rinse off thoroughly with clean water. Be sure to remove all detergent residues, as they can be harmful to plastic parts.

After washing

- 1. Dry the vehicle with a chamois or absorbent towel, preferably microfiber terrycloth.
- 2. For drive chain-equipped models: Dry and then lubricate the drive chain to prevent rust.

- 3. Use a chrome polish to shine chrome, aluminum, and stainless steel parts. Often the thermally induced discoloring of stainless steel exhaust systems can be removed through polishing.
- 4. Apply a corrosion protection spray on all metal parts including chrome or nickel-plated surfaces. WARNING! Do not apply silicone or oil spray to seats, hand grips, rubber foot pegs or tire treads. Otherwise these parts will become slippery, which could cause loss of control. Thoroughly clean the surfaces of these parts before operating the vehicle. [EWA20651]
- 5. Treat rubber, vinyl, and unpainted plastic parts with a suitable care product.
- 6. Touch up minor paint damage caused by stones, etc.
- 7. Wax all painted surfaces using a non-abrasive wax or use a detail spray for motorcycles.

FAU83472

Scooter care and storage

- 8. When finished cleaning, start the engine and let it idle for several minutes to help dry any remaining moisture.
- 9. If the headlight lens has fogged up, start the engine and turn on the headlight to help remove the moisture.
- 10. Let the vehicle dry completely before storing or covering it.

ECA26320

NOTICE

- Do not apply wax to rubber or unpainted plastic parts.
- Do not use abrasive polishing compounds as they will wear away the paint.
- Apply sprays and wax sparingly. Wipe off excess afterwards.

EWA20660

WARNING

Contaminants left on the brakes or tires can cause loss of control.

- Make sure there is no lubricant or wax on the brakes or tires.
- If necessary, wash the tires with warm water and a mild detergent.

- If necessary, clean the brake discs and pads with brake cleaner or acetone.
- Before riding at higher speeds. test the vehicle's braking performance and cornering behavior.

Storage

Always store the vehicle in a cool, dry place. If necessary, protect it against dust with a porous cover. Be sure the engine and the exhaust system are cool before covering the vehicle. If the vehicle often sits for weeks at a time between uses, the use of a quality fuel

stabilizer is recommended after each

ECA21170

NOTICE

fill-up.

- Storing the vehicle in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.
- To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.

Long term storage

Before storing the vehicle long term (60 days or more):

Scooter care and storage

- 1. Make all necessary repairs and perform any outstanding maintenance.
- 2. Follow all instructions in the Care section of this chapter.
- 3. Fill up the fuel tank, adding fuel stabilizer according to product instructions. Run the engine for 5 minutes to distribute treated fuel through the fuel system.
- 4. For vehicles equipped with a fuel cock: Turn the fuel cock lever to the off position.
- For vehicles with a carburetor: To prevent fuel deposits from building up, drain the fuel in the carburetor float chamber into a clean container. Retighten the drain bolt and pour the fuel back into the fuel tank.
- 6. Use a quality engine fogging oil according to product instructions to protect internal engine components from corrosion. If engine fogging oil is not available, perform the following steps for each cylinder:
 - a. Remove the spark plug cap and spark plug.

- b. Pour a teaspoonful of engine oil into the spark plug bore.
- c. Install the spark plug cap onto the spark plug, and then place the spark plug on the cylinder head so that the electrodes are grounded. (This will limit sparking during the next step.)
- d. Turn the engine over several times with the starter. (This will coat the cylinder wall with oil.) WARNING! To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.

[EWA10952]

- e. Remove the spark plug cap from the spark plug, and then install the spark plug and the spark plug cap.
- 7. Lubricate all control cables, pivots, levers and pedals, as well as the sidestand and centerstand (if equipped).
- 8. Check and correct the tire air pressure, and then lift the vehicle so that all wheels are off the ground. Otherwise, turn the

- wheels a little once a month in order to prevent the tires from becoming degraded in one spot.
- 9. Cover the muffler outlet with a plastic bag to prevent moisture from entering it.
- 10. Remove the battery and fully charge it, or attach a maintenance charger to keep the battery optimally charged. *NOTICE:* Confirm that the battery and its charger are compatible. Do not charge a VRLA battery with a conventional charger. [ECA26330]

TIP

- If the battery will be removed, charge it once a month and store it in a temperate location between 0-30 °C (32-90 °F).
- See page 8-27 for more information on charging and storing the battery.

Dimensions: Engine oil: Rear tire: Overall length: SAE viscosity grades: Type: 1850 mm (72.8 in) 10W-40 **Tubeless** Recommended engine oil grade: Overall width: Size: 685 mm (27.0 in) API service SG type or higher, JASO 110/70-12 47L Overall height: standard MB Manufacturer/model: 1075 mm (42.3 in) Engine oil quantity: MAXXIS/M6220 Seat height: Oil change: Loading: 0.80 L (0.85 US at, 0.70 Imp.qt) 750 mm (29.5 in) Maximum load: Final transmission oil: Wheelbase: 158 kg (348 lb) 1280 mm (50.4 in) (Total weight of rider, passenger, cargo and Type: Ground clearance: Motor oil SAE 10W-40 type SG or higher accessories) 135 mm (5.31 in) Quantity: Front brake: Minimum turning radius: 0.10 L (0.11 US qt, 0.09 Imp.qt) Type: 1.9 m (6.23 ft) Fuel: Hydraulic single disc brake Weight: Recommended fuel: Rear brake: Curb weight: Unleaded gasoline only Type: 95 kg (210 lb) (LCP125) Fuel tank capacity: Mechanical leading trailing drum brake 95 kg (211 lb) (LCP125-I) 5.1 L (1.3 US gal, 1.1 Imp.gal) Front suspension: **Engine:** Fuel reserve amount: Type: Combustion cycle: 0.2 L (0.07 US gal, 0.06 Imp.gal) Telescopic fork 4-stroke **Fuel injection: Rear suspension:** Cooling system: Throttle body: Type: Air cooled ID mark: Unit swing BEJ1 Valve train: **Electrical system:** SOHC Front tire: System voltage: Number of cylinders: Type: 12 V Single cylinder **Tubeless Battery:** Displacement: Size: Model: 124.86 cm³ 110/70-12 47L YTZ6V Bore × stroke: Manufacturer/model: Voltage, capacity: $52.4 \times 57.9 \text{ mm} (2.06 \times 2.28 \text{ in})$ MAXXIS/M6219Y 12 V, 5.0 Ah (10 HR) Starting system: Electric starter

Specifications

Bulb wattage:

Headlight:

LED

Brake/tail light:

21.0 W/5.0 W

Front turn signal light:

10.0 W

Rear turn signal light:

10.0 W

Auxiliary light:

LED

Consumer information

EAU26366

Identification numbers

Record the vehicle identification number and the engine serial number in the spaces provided below for assistance when ordering spare parts from a Yamaha dealer or for reference in case the vehicle is stolen.

VEHICLE IDENTIFI	ICATION NUMBER:
------------------	-----------------

ENGINE SERIAL NUMBER:	

Vehicle identification number



1. Vehicle identification number

The vehicle identification number is stamped into the frame under the passenger seat.

TIP


The vehicle identification number is used to identify your vehicle and may be used to register it with the licensing authority in your area.

To check the vehicle identification number

- 1. Open the seat. (See page 5-16.)
- 2. Remove the CCU cover. (See page 4-4.)

Engine serial number

EAU26442



1. Engine serial number

The engine serial number is stamped into the crankcase.

Consumer information

EAUA1021

Use of your data

This is a brief summary of how Yamaha (Yamaha Motor Co., Ltd., and the local subsidiaries) uses your data. For more details for Yamaha's use of your data, please see our Privacy Policy. https://global.yamaha-motor.com/en/privacy/

What data we collect? and How we collect your data?

This vehicle collects three types of data through integrated Engine Control Units (ECU).:

(1) Vehicle Identification Number (VIN); (2) live data showing the performance of the vehicle such as engine/motor operating state, vehicle speed, mileage; and (3) other data showing the status of the vehicle such as diagnostic trouble code (DTC). The collected data will be uploaded to server at Yamaha Motor Co., Ltd. by attaching a special Yamaha diagnostic tool to the vehicle, only when maintenance checks or service procedures are performed.

How will we use your data?

Yamaha use collected data from your vehicle, (1) to conduct adequate maintenance service including diagnostics, (2) to implement proper warranty claim judgement, (3) to conduct research and development of vehicle, (4) to provide and improve quality of products, features, and services, (5) to ensure our business purpose, and (6) to comply with legal obligations or lawful orders, and to establish or defend legal claims.

How we share your data?

We may share your data with: (i) our subsidiaries, affiliates, and business partners; (ii) dealers and distributors in your country or region, and (iii) contractors within the scope necessary to achieve the purpose of use described above.

How to contact us

Any questions or complaints regarding the processing of your Personal Data can be submitted in writing to the local subsidiaries.

https://global.yamaha-motor.com/link/

Consumer information

The SOLE PURPOSE of above provided contact information is TO RESPOND DATA PROCESSING INQUIRY AND OTHER KINDS OF INQUIRIES WILL NOT BE RESPONDED. Please provide the following information for the proper handling of your inquiry: (1) Your Name; (2) Your Email Address; (3) Your Country of Residence; and (4) Your VIN. We will use your personal information provided only for the purpose of supporting your data processing inquiry.

<u>Index</u>

A	Engine trouble warning light 5-6	Multi-function display5-
Acceleration and deceleration7-3	F	Multi-function meter unit
Acceleration assist indicator light5-6	Final transmission oil8-14	(for LCP125-I)5-
Activating the Stop and Start System4-1	Front brake lever free play, checking 8-20	P
Air filter and V-belt case air filter	Front fork, checking8-26	Panels, removing and installing8-
elements8-15	Fuel5-14	Parking7-
Answer-back remote (for equipped	Fuel consumption, tips for reducing 7-4	Part locations3-
models)5-1	Fuel meter 5-8	Power outlet5-1
В	Fuel tank cap5-14	Precautions when using the
Battery8-27	Fuses, replacing8-29	Stop and Start System4-
Brake fluid, changing8-23	H	R
Brake fluid level, checking8-22	Handlebar switches5-11	Rear brake lever free play, adjusting8-2
Brake lever, front5-12	Hazard lights switch5-12	Rear brake lever lock5-1
Brake lever, rear5-13	Helmet holders 5-16	S
Brake levers, lubricating8-24	Helmets2-6	Safe-riding points2-
Brake pads and shoes, checking8-21	High beam indicator light 5-5	Safety information2-
Braking7-4	Horn switch 5-12	Seat5-1
C	I	Sidestand5-1
Cables, checking and lubricating8-24	Identification numbers11-1	Smartphone battery level meter5-
Care9-1	Ignition circuit cut-off system 5-20	Spark plug, checking8-1
Catalytic converter5-15	Incoming call icon5-7	Special features4-
CCU (Communication Control Unit)	Incoming notification icon 5-7	Specifications10-
(for equipped models)4-4	Indicator lights and warning lights 5-5	Speedometer5-
Centerstand and sidestand,	K	Speedometer unit (for LCP125)5-
checking and lubricating8-25	Keyhole shutter 5-4	Starting off7-
Clock5-10	L	Starting the engine7-
D	Labels, location 1-1	Start switch5-1
Dimmer switch5-11	Luggage hook5-18	Steering, checking8-2
E	M	Stop and Start System4-
ECO" indicator5-11	Main switch/steering lock 5-3	Stop and Start System indicator light 5-
Eco indicator light5-6	Maintenance and lubrication, periodic 8-3	Stop and Start System operation4-
Engine break-in7-1	Maintenance, emission control	Stop and Start System switch5-1
Engine oil and oil strainer8-12	system8-2	Stop and Start System
Engine serial number11-1	Matte color. caution9-1	troubleshooting8-3

Storage	9-3
Storage compartments	5-17
T	
Tail/brake light bulb or rear turn	
signal light bulb, replacing	8-3-
Throttle grip and cable,	
checking and lubricating	8-2/
Throttle grip free play, checking	
Tires	
Tool kit	
Troubleshooting	
Troubleshooting chart	
Turn signal indicator lights	5-5
Turn signal light bulb (front),	
replacing	
Turn signal switch	5-1
U	
Use, your vehicle data	11-2
V	
Valve clearance	8-18
V-belt, checking	
Vehicle identification number	
Vehicle lights	
W	
	9.07
Wheels	
Wheels	0-20
Y	
Yamaha Motorcycle Connect icon	5-8

Yamaha Motorcycle Connect





