



# TROUBLE SHOOTING GUIDE


TSG-2020-0006

<b>DATE</b>	28/11/2020	<b>ISSUE BY</b>	zaidi	<b>CHECK BY</b>	Rashid	<b>APP.BY</b>	Mazmin
-------------	------------	-----------------	-------	-----------------	--------	---------------	--------

<b>MODEL</b>	NVX	<b>PROBLEM</b>	bike cannot start
--------------	-----	----------------	-------------------

<b>SYMPTOM</b>	sunddely die off while riding (no code appear)
----------------	--

<b>PHOTO</b>			<p>wire fuel pump break / damage</p>
--------------	---	---	--------------------------------------

ITEMS	DESCRIPTION	PHOTO	
<b>Check Point</b>	Step 1	Check fuse	
	Step 2	Check connection socket fuel pump	
	Step 3	Check relay fuel pump	
	Step 4	There is no flow pressure at the fuel pump	
<b>Problem Finding</b>	Step 1	Fuel pump comp wire break for motor pump	
	Step 2		
<b>Action Taken</b>	Step 1	Replace the fuel pump assy .	
	Step 2		
<b>Test Result</b>	1	problem solved.	
	2	Tested -ok-	
	3		